

## NOVA / SUPERNOVA CALIBRATION INSTRUCTIONS

1. Power the scale on.
2. Press the **“ON/TARE/OFF”** button in ½ second intervals 3 times and the 4th time held down, making a total of 4 presses (Example: Must be quick presses 1, 2, 3 & hold on 4th) until the LCD displays a digital range within **“-4000 – 12000”**.
3. Press the **“ON/TARE/OFF”** button; the LCD will now display the required weight for calibration, depending on scale model.  
**Nova [P21PL-M]**: 1000g (1 kg), **Supernova [P136PL-C]**: 6000g (6 kg)
4. Gently place the required weight onto the scale platform.
5. After your platform is stable from any movement, press the **“ON/TARE/OFF”** button. The LCD will briefly display **“CAL”**, and then **“PASS”** for successful calibration. (**“EEEE”** will appear if calibration failed.)
6. Calibration is now completed; power the scale off and restart.