

## PRIMO CALIBRATION INSTRUCTIONS

1. Power the scale on.
2. Press the **“ON/TARE/OFF”** button in ½ second intervals 4 times total following with a button hold on the 4<sup>th</sup> press. (Example: Must be quick presses 1, 2, 3, 4 -- HOLD) until the LCD displays a randomized negative value.
3. Press the **“ON/TARE/OFF”** button; the LCD will now display the required weight for calibration: 5000g (5 kg)
4. Gently place the required weight onto the center of the scale platform.
5. After your platform is stable from any movement, press the **“ON/TARE/OFF”** button. The LCD will briefly display **“CAL”**, and then **“PASS”** for successful calibration. (**“EEEE”** will appear if calibration failed.)
6. Calibration is now completed; power the scale off and restart.